



Baud2:Baud1:Baud0 = Baudrate

0:0:0 = 9.6kbps
 0:0:1 = 19.2kbps
 0:1:0 = 38.4kbps
 0:1:1 = 57.6kbps
 1:0:0 = 115.2kbps (*)
 1:0:1 = 230.4kbps
 1:1:0 = 460.8kbps
 1:1:1 = 921.6kbps

Role

0 = Slave (*)
 1 = Master

OpMode

0 = Automatic Operation (*)
 -> Slave mode waits for connect
 -> Master Mode tries to connect (but needs passkey)
 1 = Normal Operation
 -> not sure exactly what this does. (AT commands enabled?)

MsgEnable

0 = allow system messages (*)
 -> On stamp/reset: "Init 1.04.0 (Build 365)"
 -> On Connection: "CONxxxxxxxxx"
 -> On Disconnect: "DCO"
 1 = silent

| Title | | |
|-------|------------------------------------|-----------|
| Size | Number | Revision |
| B | | |
| Date: | 7/22/2005 | Sheet of |
| File: | Z:\DATA-MEng\...\TestBoard1.SCHDOC | Drawn By: |