



Baud2:Baud1:Baud0 = Baudrate

0:0:0 = 9.6kbps
 0:0:1 = 19.2kbps
 0:1:0 = 38.4kbps
 0:1:1 = 57.6kbps
 1:0:0 = 115.2kbps (*)
 1:0:1 = 230.4kbps
 1:1:0 = 460.8kbps
 1:1:1 = 921.6kbps

Role

0 = Slave (*)
 1 = Master

OpMode

0 = Automatic Operation (*)
 -> Slave mode waits for connect
 -> Master Mode tries to connect (but needs passkey)
 1 = Normal Operation
 -> not sure exactly what this does. (AT commands enabled?)

MsgEnable

0 = allow system messages (*)
 -> On stamp/reset: "Init 1.0.4.0 (Build 365)"
 -> On Connection: "CONxxxxxxxxxx"
 -> On Disconnect: "DCO"
 1 = silent

Title		
Size	Number	Revision
B		
Date:	7/22/2005	Sheet of
File:	Z:\DATA-MEng\...\TestBoard1.SCHDOC	Drawn By: